



BASICS Equipment Ltd

72 High Street
Selsey
Chichester
West Sussex
PO20 0QJ

Telephone: 01243 607029

www.basicsequipment.co.uk
e-mail: davidbooth@basicsequipment.co.uk

PRODUCT SAFETY & MAINTENANCE DATASHEET

Customer	Product/Quantity	Supplier
ESPO (Various delivery sites as per order).	Wall mounted, single & double side floor mounted scooter racks. Combination Bike & scooter racks	BASICS Equipment Ltd 72 High Street Selsey Chichester West Suseex PO20 0QJ
	BASICS Order Number	
	Not Applicable	
Site Address		Month/Year of Supply
As per ESPO purchase orders		As per ESPO purchase orders
General Product Description		
<p>Wall mounted scooter racks – galvanised finish. Capacities 8 to 15 scooters.</p> <p>Single sided floor mounted scooter racks – galvanised finish. Capacities 8 to 15 scooters.</p> <p>Double sided floor mounted scooter racks – galvanised finish. Capacities 16 to 30 scooters.</p> <p>Combination floor mounted bike & scooter racks. Capacities: 4 bikes + 10 scooters, 6 bikes + 12 scooters, 5 bikes + 15 scooters.</p> <p>Galvanised is a Hot dipped Galvanised Finish for weather protection the galvanising is to EN ISO1461</p> <p>The product has a 1 year warranty against faulty materials & workmanship</p>		
(1 of 2)		Continued.....

ESPO Wall mounted scooter racks, single & double sided floor mounted scooter racks, combination bike & scooter racks. Product safety & Maintenance Sheet –

continued... (2 of 2)

Maintenance/Operation

The Scooter racks are fixed items with no moving parts. After they have been fixed in position they are static and should not require maintenance as such. It is recommended there is a regular inspection to ensure that there are no damaged areas. If a Rack has been damaged that unit should be taken out of service and a new replacement fitted.

Minor repairs can be made to a small damaged section of the galvanising with a cold galvanising spray.

Floor mounted rack frames are secured to the end posts with appropriate bolts/nuts The inspection should also include a check for any loose bolts. If any are found the unit should be taken out of service until replacement fixings are in place.

For Bolt-down surface installations and wall fix installations BASICS include Free of Charge proprietary masonry bolts. It is entirely the responsibility of the installing personnel to ensure the bolts are suitable for where the racks are being fixed.

During the regular inspection described above all ground bolts should be checked and if any loose bolts found the unit taken out of service until replacements fitted.

Floor mounted racks for concreting in below the ground have longer posts, these should be concreted in with a product appropriate to ground conditions. During the regular inspection the fixing should be checked if any rack is found to be loose the unit taken out of service until it can be re-fixed in position.

Date of Issue	6th June 2024	Initialled	DBB
----------------------	---------------------------------	-------------------	------------